

Grille de réglages de hauteurs sol-siège du Freelance

AVANT			
	Position (de haut en bas)	Fourche standard 53mm	Fourche longue 180x45mm
8"	1	X	X
	2	X	50,25
	3	49,75	51,5
	4	51	52,75
	5	X	54
7"	1	X	47,75
	2	47,25	49
	3	48,5	50,25
	4	49,75	51,5
	5	X	52,75
6"	1	44,75	46,5
	2	46	47,75
	3	47,25	49
	4	48,5	50,25
	5	X	51,5
5"	1	X	X
	2	44,75	46,5
	3	46	47,75
	4	47,25	49
	5	X	50,25
4"	1	X	X
	2	43,5	X
	3	44,75	46,5
	4	46	47,75
	5	X	49
3"	1	X	X
	2	X	X
	3	43,5	X
	4	44,75	46,5
	5	X	47,75

ARRIÈRE		
	Position (de haut en bas)	Hauteur sol-siège
24"	1	43,75
	2	45
	3	46,25
	4	47,5
	5	49,75
	6	51
22"	1	41,25
	2	42,5
	3	43,75
	4	45
	5	47,25
	6	48,5
25"	1	45
	2	46,25
	3	47,5
	4	48,75
	5	51
	6	52,25
26"	1	46,25
	2	47,5
	3	48,75
	4	50
	5	52,25
	6	53,5